


INSTRUCTIONS:

1. FLASH TANK HALVES AS NECESSARY.
2. LINE THE TANK HALVES UP AND SECURE THEM TOGETHER USING CONNECTING PIN PROVIDED.
3. CHECK S.U.M.O. INSERTS TO ENSURE THEY ARE SEATED PROPERLY.
4. PLACE S.U.M.O. FITTING PACKAGES INTO WARRANTY PACKAGE.
5. INSTALL 2 EA. TRANSPORT LID ASSEMBLIES PER THE CUTSHEET FOR THOSE LIDS.
6. DRILL 3 GROUPS OF 3 EACH \varnothing 1/4" HOLES EVENLY SPACED IN SPLASH GUARD 1" BELOW STEP.
7. CLEAN TANK INSIDE AND OUT.
8. ATTACH WARRANTY PACKAGE TO A SPLASH GUARD VENT HOLE.
9. PLACE ASSEMBLED TANK INTO STEEL SKID (NOT SHOWN).
10. PLACE HOOPS OVER TANK AND ATTACH TO SKID.
11. INSTALL CAPPLUGS INTO S.U.M.O. FITTINGS.
12. INSTALL LADDER (NOT SHOWN).



(080) NOT SHOWN

(090) NOT SHOWN

SEE BILL OF MATERIALS FOR A COMPLETE LIST OF COMPONENTS INCLUDING POWDER AND PIGMENT. ALL DIMENSIONS, DESIGNS, AND INFORMATION ON THIS PRINT MUST BE CONSIDERED PROPRIETARY TO SNYDER INDUSTRIES, INC. AND MAY NOT BE USED, COPIED, OR DISTRIBUTED WITHOUT WRITTEN PERMISSION OF AN OFFICER (OR HIS AGENT) OF THE FIRM.

SNYDER INDUSTRIES INC. LINCOLN, NE. 68504 PRODUCTION PROCESS INSTRUCTIONS

PART DESCRIPTION:
ASM TK 3250HSB DUAL W/3" SUMOS

DRAWN BY:RDG | DATE:03/30/2005 | PART NUMBER: 8700000C--